



WALL BASE MOULDING

Thank you for choosing this fine product from GRIOT'S GARAGE. Your WALL BASE MOULDING adds a finishing touch to your garage for a professional look. Enjoy the best.

USEFUL INFORMATION

Before installing the WALL BASE MOULDING, be sure surface is smooth and free from old adhesive, oil, grease, loose paint, or other foreign matter. Cut and remove any wallpaper up to 1/2 inch below the top of the WALL BASE MOULDING. For newly painted surfaces, allow at least two weeks curing time before installing WALL BASE MOULDING. Apply two strips of double-backed SELF ADHESIVE TAPE along the top and bottom edges to each four-foot piece of WALL BASE MOULDING. Set the WALL BASE MOULDING into place and press it firmly against the wall with the palm of your hand working out from the corner to the center of the wall. Be certain the bottom edge touches the floor, as you will not be able to slide the WALL BASE MOULDING down the wall once attached. Press the toe of the WALL BASE MOULDING firmly against the wall using a straight piece of wood.

DISCLAIMER

GRIOT'S GARAGE is not responsible for any misuse of the WALL BASE MOULDING and SELF ADHESIVE TAPE OR for any injury or damage incurred to any person or object related to the WALL BASE MOULDING and SELF ADHESIVE TAPE.

ANSWERS TO YOUR QUESTIONS

Should you want to order more WALL BASE MOULDING, additional rolls of SELF ADHESIVE TAPE or for a complete selection of quality GRIOT'S GARAGE products, please write or call us toll-free at 800-345-5789 You can use the internet at www.griotsgarage.com. Reorder item number 92334 for the WALL BASE MOULDING or item number 92455 for the SELF ADHESIVE TAPE.

Have fun in your garage!

GRIOT'S GARAGE, INC.
3333 SOUTH 38th STREET
TACOMA, WA 98409
800-345-5789
www.griotsgarage.com

© GRIOT'S GARAGE, INC.

